

Apple Pencil

Apple Pencil uses Bluetooth® technology to connect to iPad Pro.

Pair and charge Apple Pencil

Pair and charge Apple Pencil with iPad Pro:

- 1 Lay iPad Pro on a flat surface.
- 2 Pull the top of the end of Apple Pencil to expose the Lightning connector.
- 3 Plug the end of Apple Pencil into the Lightning connector on iPad Pro.



2 Connect the Lightning to USB Cable to

safe distance of separation between your medical device and Apple Pencil. Consult your physician and medical device manufacturer for information specific to your medical device. Stop using Apple Pencil if you suspect it is interfering with your pacemaker, defibrillator, or any other medical device.

Cleaning

To clean the outside of Apple Pencil, use a lint-free cloth. Don't get moisture in any openings or use aerosol sprays, solvents, or abrasives.

Ergonomics

When using Apple Pencil, it's important to find a comfortable posture, change your position often, and take frequent breaks.

For information about ergonomics, health, and safety, visit the Ergonomics website at www.apple.com/about/ergonomics.

Support

For support and troubleshooting information, user discussion boards, and the latest Apple software downloads, go to www.apple.com/support.

FCC Compliance Statement

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found

Malaysia



Australia/New Zealand



Japan VCCI Class B Statement



resources and ensure that it is recycled in a manner that protects human health and the environment.

Union Européenne—informations sur l'élimination

Le symbole ci-dessus signifie que, conformément aux lois et réglementations locales, vous devez jeter votre produit et/ou sa batterie séparément des ordures ménagères. Lorsque ce produit arrive en fin de vie, apportez-le à un point de collecte désigné par les autorités locales. La collecte séparée et le recyclage de votre produit et/ou de sa batterie lors de sa mise au rebut aideront à préserver les ressources naturelles et à

© 2015 Apple Inc. All rights reserved.

Apple, the Apple logo, and iPad are trademarks of Apple, registered in the U.S. and other countries. Apple Pencil and Lightning are trademarks of Apple Inc.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Apple is under license.

Printed in XXXX.

034-00830-A